

■印西市文化ホール 舞台道具リスト

名称	備考	総数	舞台 下手	舞台 上手	照明 倉庫	ホリ 裏	下手 階段 1F	上手 階段 1F	上手 階段 M2F	下手 客席 倉庫	ピア ノ庫	ホウ イエ 階段	多目 的室
音響反射板		1式											
所作台	3尺×2間	20		20									
所作台化粧カマチ	幅=2間	3		3									
	幅=1.5間	1		1									
所作台用開帳場		2		2									
平台	6尺×6尺	4				4							
	4尺×6尺	10				10							
	3尺×6尺	20			2	18							
	2尺×6尺	10				10							
	3尺×4尺	4							4				
	3尺×3尺	4							4				
変形平台	3尺×3尺	4						4					
開き足(高足)	6尺×2.4尺	6							6				
	4尺×2.4尺	6			6								
	3尺×2.4尺	6				6							
開き足(中足)	6尺×1.7尺	6							6				
	4尺×1.7尺	6				6							
	3尺×1.7尺	6				6							
箱馬	6寸×1尺×1.7尺	20			20								
	6寸×1尺×1.1尺	28			28								
木足	3寸×3寸×1尺	44			44								
人形立て		18	18										
板ケコミ	2.8尺×6尺	5	5										
	2.1尺×6尺	5	5										
	1.4尺×6尺	5	5										
	1尺×6尺	6	6										
	7寸×6尺	9	9										
上敷	3尺×7間	3			3								
	3尺×3.5間	5			5								
	3尺×2間	7			7								
緋毛氈	1間×2間	5			5								
	1間×1間	5			5								
座布団	高座用座布団(赤)	1			1								
	高座用座布団(紫)	1			1								
	床几用長座布団(赤) / ≒1.820×≒545	2			2								
松羽目	7間×3間/7バトン常設	1											
屏風	金屏風	1双		1双									
	銀屏風	1双		1双									
	鳥の子	1双		1双									
講演台	1,500(W)/900(D)/990(H)	1	1										
講演台用花台	600(W)/700(D)/690(H)	2	2										
司会者台	800(W)/650(D)/1,050(H)	1	1										
横看板	4,000(W)/900(H)※連結時8,000(W)	2					2						
市旗・県旗・国旗	1,500(W)/1,000(H)	各1		各1									
めくり	背板有り 420(W)/1,510(H)*背板(W=300)	1					1						
	背板なし 420(W)/1,510(H)	1					1						
リノリウム	12,000(W)/1,820(D)	7	7										
地がすり(グレー)	7間×7間	1			1								
紗幕(白)	7間×3間	1			1								
指揮台	WENGER(背有り)810(W)/960(D)/145(H)	1					1						
	WENGER(背なし)1,090(W)/960(D)/145(H)	1					1						
	松尾楽器(背有り)1,200(W)/900(D)/315(H)	1	1										
指揮者用譜面台	WENGER	1					1						
	松尾楽器	1					1						
演奏者用譜面台	WENGER	72						50	22				
	OHASHI	8	8										

■印西市文化ホール 舞台道具リスト

名称	備考	総数	舞台 下手	舞台 上手	照明 倉庫	ホリ 裏	下手 階段 1F	上手 階段 1F	上手 階段 M2F	下手 客席 倉庫	ピア ノ庫	ホワイエ 階段	多目 的室
長机	キャスター付き2つ折り 1,800(W)/450(D)	15	15										
	幕板付折りたたみ 1,800(W)/450(D)	4					4						
	折りたたみ 1,800(W)/450(D)	5								5			
折りたたみイス		50	50										
演奏者用イス	WENGER	79						30	49				
ピアノイス	ベンチ	2									2		
	トムソン	3									3		
チェロイス	WENGER	8							8				
バスイス	WENGER	6							6				
展示パネル													●
展示パネル用支柱													●
ホワイトボード		1			1								
ピアノ	スタインウェイ(D-274)	1									1		
	ペーゼンドルファー(Model 275)	1									1		
ティンパニー	LUDWIG(32", 29", 26", 23", 21")	各1									各1		
バスドラム	YAMAHA	1									1		
マリンバ	YAMAHA	1									1		
ビブラフォン	YAMAHA/YV-3000	1									1		
チャイム	YAMAHA/CH-500	1									1		
ドラ		1									1		
和太鼓	長胴太鼓(2尺)	1									1		
ホワイエ用長机		6										6	
ホワイエ用イス		47										47	